

VOICE	PARAMETER	MODIFICATION
Bass Drum	Tune 1	replace R29 with a 1M pot
	Tune 2	replace R27 with a 1M pot
Snare Drum	Tune	replace R98 with 1M pot
	Decay	1M pot in series with R100
	Snappy	replace R34 with 100K pot
Clap	Snappy	replace R202 with 1M pot
	Filter	replace R147 with 100K pot
Hi Hats/Cymbal	Filter	100K pot in series with R218
Hi Hats	Decay	replace R154 with 500K pot
Cowbell	Tune 1	replace VR12 with 1M pot
	Tune 2	replace VR13 with 1M pot
	Decay	replace R67 with 500K pot
Rim Shot	Filter	replace R269 with 100K pot
Toms	Low Tom Tune	replace R9 with 100K pot
	High Tom Tune	replace R42 with 100K pot